

NCBI Bookshelf. A service of the National Library of Medicine, National Institutes of Health.

StatPearls [Internet]. Treasure Island (FL): StatPearls Publishing; 2020 Jan-.

Ventilator Management

Authors

Andres L. Mora Carpio; Jorge I. Mora¹.

Affiliations

¹ University of Pennsylvania

Last Update: March 28, 2020.

Introduction

The need for mechanical ventilation is one of the most common causes of admission to the intensive care unit.[1][2][3]

It is first imperative to understand some basic terms to understand mechanical ventilation.

- **Ventilation:** Exchange of air between the lungs and the air (ambient or delivered by a ventilator), in other words, it is the process of moving air in and out of the lungs. Its most important effect is the removal of carbon dioxide (CO₂) from the body, not on increasing blood oxygen content. Ventilation is measured as minute ventilation in the clinical setting, and it is calculated as respiratory rate (RR) times tidal volume (V_t). In a mechanically ventilated patient, the CO₂ content of the blood can be modified by changing the tidal volume or the respiratory rate.
- **Oxygenation:** Interventions that provide greater oxygen supply to the lungs, thus the circulation. In a mechanically ventilated patient, this can be achieved by increasing the fraction of inspired oxygen (FiO₂) or the positive end-expiratory pressure (PEEP).
- **PEEP:** The positive pressure that will remain in the airways at the end of the respiratory cycle (end of exhalation) that is greater than the atmospheric pressure in mechanically ventilated patients. For a full description of the use of PEEP, please review the article titled “Positive End-Expiratory Pressure (PEEP).”
- **Tidal volume:** Volume of air moved in and outside the lungs in each respiratory cycle.
- **FiO₂:** Percentage of oxygen in the air mixture that is delivered to the patient.
- **Flow:** Speed in liters per minute at which the ventilator delivers breaths.
- **Compliance:** Change in volume divided by change in pressure. In respiratory physiology, total compliance is a mix of lung and chest wall compliance as this two factors cannot be separated in a live patient.

Since having a patient on mechanical ventilation allows a practitioner to modify the patient’s ventilation and oxygenation, it has an important role in acute hypoxic and hypercapnic respiratory failure as well as in severe metabolic acidosis or alkalosis.[4][5]

Physiology of Mechanical Ventilation

Mechanical ventilation has several effects on lung mechanics. Normal respiratory physiology works as a negative pressure system. When the diaphragm pushes down during inspiration, a negative pressure in the pleural cavity is generated, this, in turn, creates negative pressure in the airways that suck air into the lungs. This same negative intrathoracic pressure decreases the right atrial (RA) pressure and generates a sucking effect on the inferior vena cava (IVC), increasing venous return. The application of positive pressure ventilation changes this physiology. The positive pressure generated by the ventilator transmits to the upper airways and finally to the alveoli, this, in turn, is transmitted to the alveolar space and thoracic cavity, creating positive pressure (or at least less negative pressure) in the pleural

space. The increased RA pressure and decreased venous return generate a decrease in preload. This has a double effect in decreasing cardiac output: Less blood in the right ventricle means less blood reaching the left ventricle and less blood that can be pumped out, decreasing cardiac output. Less preload means that the heart works at a less efficient point in the Frank-Starling curve, generating less effective work and further decreasing cardiac output, which will result in a drop in mean arterial pressure (MAP) if there is not a compensatory response by increasing systemic vascular resistance (SVR). This is a very important point to have in mind especially in patients who may not be able to increase their SVR, like in patients with distributive shock (septic, neurogenic, or anaphylactic shock).

On the other hand, mechanical ventilation with positive pressure can significantly decrease the work of breathing. This, in turn, decreases blood flow to respiratory muscles and redistributes it to more critical organs. Reducing the work from respiratory muscles also reduces the generation of CO₂ and lactate from these muscles, helping improve acidosis.

The effects of mechanical ventilation with positive pressure on the venous return may be beneficial when used in patients with cardiogenic pulmonary edema. In these patients with volume overload, decreasing venous return will directly decrease the amount of pulmonary edema being generated, by decreasing right cardiac output. At the same time, the decreased return may improve overdistension in the left ventricle, placing it at a more advantageous point in the Frank-Starling curve and possibly improving cardiac output.

Proper management of mechanical ventilation also requires an understanding of lung pressures and lung compliance. Normal lung compliance is around 100 ml/cmH₂O. This means that in a normal lung the administration of 500 ml of air via positive pressure ventilation will increase the alveolar pressure by 5 cm H₂O. Conversely, the administration of a positive pressure of 5 cm H₂O will generate an increase in lung volume of 500 mL. In real life, we rarely work with normal lungs, and compliance may be much higher or much lower. Any disease that destroys lung parenchyma like emphysema will increase compliance, any disease that generates stiffer lungs (ARDS, pneumonia, pulmonary edema, pulmonary fibrosis) will decrease lung compliance.

The problem with stiff lungs is that small increases in volume can generate large increases in pressure and cause barotrauma. This generates a problem in patients with hypercapnia or acidosis as there may be a need to increase minute ventilation to correct these problems. Increasing respiratory rate may manage this increase in minute ventilation, but if this is not feasible, increasing the tidal volume can increase plateau pressures and create barotrauma.

There are two important pressures in the system to be aware of when mechanically ventilating a patient:

1. Peak pressure is the pressure achieved during inspiration when the air is being pushed into the lungs and is a measure of airway resistance.
2. Plateau pressure is the static pressure achieved at the end of a full inspiration. To measure plateau pressure, we need to perform an inspiratory hold on the ventilator to permit for the pressure to equalize through the system. Plateau pressure is a measure of alveolar pressure and lung compliance. Normal plateau pressure is below 30 cm H₂O, and higher pressure can generate barotrauma.

Issues of Concern

Indications for Mechanical Ventilation

The most common indication for intubation and mechanical ventilation is in cases of acute respiratory failure, be it hypoxic or hypercapnic failure.

Other important indications include a decreased level of consciousness with an inability to protect the airway, respiratory distress that failed non-invasive positive pressure ventilation, cases of massive hemoptysis, severe angioedema or any case of airway compromise like airway burns, cardiac arrest, and shock.

Common elective indications for mechanical ventilation are surgical procedures and neuromuscular disorders.

Contraindications

There are no direct contraindications for mechanical ventilation as it is a life-saving measure in a critically ill patient, and all patients should be offered the opportunity to benefit from this if needed.

The only absolute contraindication for mechanical ventilation is if this goes against the patient's stated wishes for artificial life-sustaining measures.

The only relative contraindication is if non-invasive ventilation is available and its use is expected to resolve the need for mechanical ventilation. This should be started first as it has fewer complications than mechanical ventilation.

Preparation

In order to initiate mechanical ventilation, certain measures should be taken. Proper placement of the endotracheal tube must be verified. This may be done by end-tidal capnography or a combination of clinical and radiological findings.

Proper cardiovascular support should be ensured with fluids or vasopressors as indicated in a case by case basis.

Ensure that proper sedation and analgesia are available. The plastic tube in the patient's throat is painful and uncomfortable, and if the patient is restless or fighting the tube or the vent, it will make it much more difficult to control the different ventilation and oxygenation parameters.

Modes of Ventilation

After intubating a patient and connecting to the ventilator, it is time to select the mode of ventilation to be used. Several principles need to be grasped in order to do this consistently for the patient's benefit.

As mentioned, compliance is the change in volume divided by the change in pressure. When mechanically ventilating a patient, one can select how the ventilator will deliver the breaths. The ventilator can be set up to either deliver a set amount of volume or a set amount of pressure, and it is up to the clinician to decide which would be more beneficial for the patient. When selecting what the ventilator will deliver, you are selecting which will be the dependent and which will be the independent variable in the lung compliance equation.

If we select to start the patient on volume-controlled ventilation, the ventilator will always deliver the same amount of volume (independent variable), and the generated pressure will be dependent on the compliance. If compliance is poor, the pressure will be high, and barotrauma could ensue.

If on the other hand, we decide to start the patient on pressure-controlled ventilation, the ventilator will always deliver the same pressure during the respiratory cycle. However, the tidal volume will depend on lung compliance, and in cases where compliance frequently changes (like in asthma) this will generate unreliable tidal volumes and may cause hypercapnia or hyperventilation.

After selecting how the breath is delivered (by pressure or volume) the clinician has to decide which mode of ventilation to use. This means selecting if the ventilator will assist all the patient's breaths, some patient's breaths, or none of them and also selecting if the ventilator will deliver breaths even if the patient is not breathing on its own.

Other parameters that should be borne in mind and that can be adjusted in the ventilator are how fast the breath is delivered (flow), what will be the waveform of that flow (decelerating waveform mimics physiological breaths and is more comfortable for the patient, while square waveforms in which the flow is given at full speed during all inhalation, are more uncomfortable for the patient but deliver quicker inspiratory times), and at what rate will breaths be delivered. All these parameters should be adjusted to achieve patient comfort, desired blood gasses, and prevent air trapping.

There are many different modes of ventilation that vary minimally between each other. In this review, we will focus on the most common modes of ventilation and their clinical use. The mode of ventilation includes assist control (AC), pressure support (PS), synchronized intermittent mandatory ventilation (SIMV) and airway pressure release ventilation (APRV).

Assist Control Ventilation (AC)

Assist control is basically when the ventilator will assist the patient by delivering support for every breath the patient takes (that is the assist part), and the ventilator will have control over the respiratory rate if it goes below the set rate (control part). In assist control, if the rate is set at 12 and the patient breathes at 18, the ventilator will *assist* with the 18 breaths, but if the rate drops to 8, the ventilator will take over *control* of the respiratory rate and deliver 12 breaths in a minute.

In assist control ventilation, the breath can be delivered by either giving volume or giving pressure. This is termed volume-assist control or pressure-assist control ventilation. In order to maintain simplicity, and understanding that given that ventilation is commonly a major problem than pressure and that volume control is used overwhelmingly more commonly than pressure control, the focus for the remainder of this review will use the term "volume control" interchangeably when discussing assist control.

Assist control (volume control) is the mode of choice used in the majority of intensive care units throughout the United States because it is easy to use. Four settings can be easily adjusted in the ventilator (respiratory rate, tidal volume, FiO₂, and PEEP). The volume delivered by the ventilator in each breath in assist control will always be the same, regardless of the breath being initiated by the patient or the ventilator, and regardless of compliance, peak, or plateau pressures in the lungs.

Each breath can be time-triggered (if the patient's respiratory rate is below the set ventilator rate, the machine will deliver breaths at a set interval of time) or patient triggered if the patient initiates a breath on its own. This makes assist control a very comfortable mode for the patient as each of his or her efforts will be supplemented by the ventilator.

After making changes on the vent or after starting a patient on mechanical ventilation, careful consideration of checking arterial blood gases should be made and the oxygen saturation on the monitor should be followed to determine if further changes should be made to the ventilator.

The advantages of AC mode are increased comfort, easy corrections for respiratory acidosis/alkalosis, and low work breathing for the patient. Some disadvantages include that being a volume-cycled mode, pressures cannot be directly controlled which may cause barotrauma, the patient can develop hyperventilation with breath stacking, auto-PEEP, and respiratory alkalosis.

For a full description of Assist Control, please review the article titled "Ventilation, Assist Control." [6]

Synchronized intermittent mandatory ventilation (SIMV)

SIMV is another frequently used mode of ventilation, although its use had been falling out of favor given its less reliable tidal volumes and failure to show better outcomes when compared to AC.

"Synchronized" means that the ventilator will adjust the delivery of its breaths with the patient's efforts. "Intermittent" means that not all breaths are necessarily supported, and "mandatory ventilation" means that, as with AC, a set rate is selected and the ventilator will deliver these mandatory breaths each minute regardless of the patient's respiratory efforts. The mandatory breaths can be triggered by the patient or by time if the patient's RR is slower than the ventilator RR (as with AC). The difference from AC is that in SIMV the ventilator only will deliver the breaths that the rate is set up to deliver, any breath taken by the patient above this rate will not receive a full tidal volume or pressure support. This means that for each breath the patient takes above the set RR, the tidal volume pulled by the patient will depend solely on lung compliance and patient effort. This has been proposed as a method of "training" the diaphragm in order to maintain the muscular tone and wean off patients from the ventilator faster. Nonetheless, multiple studies have failed to show any advantages to SIMV. Furthermore, SIMV generates higher work of breathing than AC, which negatively impacts outcomes as well as generates respiratory fatigue. A general rule to go by is that the patient will be liberated from the ventilator when he or she is ready, and no specific mode of ventilation will make this faster. In the meantime, it is better to keep the patient as comfortable as possible and SIMV may not be the best mode to achieve this.

Pressure Support Ventilation (PSV)

PSV is a ventilator mode that relies completely on patient-triggered breaths. As the name implies it is a pressure-driven mode of ventilation. In this setting all breaths are patient-triggered as the ventilator has no backup rate, so each breath has to be started by the patient. In this mode, the ventilator will cycle between two different pressures (PEEP and pressure support). PEEP will be the remaining pressure at the end of exhalation, and pressure support is the pressure above the PEEP that the ventilator will administer during each breath for support of ventilation. This means that if a patient is set up in PSV 10/5, the patient will receive 5 cm H₂O of PEEP, and during inhalation, he will receive 15 cm H₂O of support (10 PS above PEEP).

Because there is no back-up rate, this mode is not for use in patients with decreased consciousness, shock, or cardiac arrest. The tidal volumes will depend solely on the patient's effort and lung compliance.

PSV often is used for ventilator weaning as it only augments patients breathing efforts but does not deliver a set tidal volume or respiratory rate.

The biggest drawback of PSV is its unreliable tidal volumes that may generate CO₂ retention and acidosis as well as the higher work of breathing which can lead to respiratory fatigue.

To address this concern, a new algorithm for PSV was created called volume support ventilation (VSV). VSV is a similar mode to PSV, but in this mode, the tidal volume is used as feedback control, as the pressure support given to the patient will be constantly adjusted to the tidal volume. In this setting, if tidal volume is decreasing, the ventilator will increase the pressure support to decrease the tidal volume and if tidal volume increases the pressure support will decrease in order to keep the tidal volume close to the desired minute ventilation. There is some evidence suggesting that the use of VSV may decrease assisted ventilation time, total weaning time and total T-piece time as well as a decreased need for sedation.

Airway pressure release ventilation (APRV)

As the name suggests, in APRV mode the ventilator will deliver a constant high airway pressure that will deliver oxygenation, and ventilation will be served by releasing that pressure.

This mode has recently gained popularity as an alternative for difficult-to-oxygenate patients with ARDS in whom other modes of ventilation fail to reach the set targets. APRV has been described as a continuous positive airway pressure (CPAP) with an intermittent release phase. What this means is that the ventilator applies a continuous high pressure (P high) for a set amount of time (T high) and then releases that pressure, usually going back to zero (P low) for a much shorter period of time (T low).

The idea behind this is that during T high (which covers 80% to 95% of the cycle), there is constant alveolar recruitment, which improves oxygenation as the time maintained on high pressure is much longer than in other types of ventilation (open lung strategy). This reduces the repetitive inflation and deflation of the lungs that happens with other ventilator modes, preventing ventilator-induced lung injury. During this time (T high) the patient is free to breathe spontaneously (which makes it comfortable) but he will be pulling low tidal volumes as exhaling against such pressure is harder. Then, when T high is reached, the pressure in the ventilator will go down to P low (usually zero). This allows for air to be rushed out of the airways allowing for passive exhalation until T low is reached and the vent delivers another breath. To prevent airway collapse during this time the T low is set short, usually around 0.4-0.8 seconds. What happens here is that when the ventilator pressure goes to zero, the elastic recoil of the lungs pushes air out, but the time is not enough for all the air to leave the lungs, so the alveolar and airway pressure does not reach zero and there is no airway collapse. This time is usually set up so that T low ends when the exhalation flow drops to 50% of the initial flow.

Minute ventilation, then, will depend on T low and the patient's tidal volumes during T high.

Indications for the use of APRV:

- ARDS that is difficult to oxygenate with AC
- Acute lung injury

- Postoperative atelectasis.

Advantages of APRV:

- APRV is a good mode for lung protection ventilation. The ability to set the P high means that the operator has control over the plateau pressure which can significantly lower the incidence of barotrauma
- Because the patient initiates his respiratory efforts, there is better gas distribution secondary to improved V/Q matching.
- Constant high pressure means more recruitment (open lung strategy)
- APRV may improve oxygenation in ARDS patients who are difficult to oxygenate on AC
- APRV may reduce the need for sedation and neuromuscular blocking agents as the patient may be more comfortable than with other modes.

Disadvantages and contraindications:

- Given that spontaneous breathing is an important aspect of APRV, it is not ideal for heavily sedated patients
- No data for APRV use in neuromuscular disorders or obstructive lung disease and its use should be avoided in this patient populations
- Theoretically, constant high intrathoracic pressure could generate high pulmonary artery pressure and worsen intracardiac shunts in patients with Eisenmenger physiology
- Strong clinical reasoning should be employed when selecting APRV as the mode of ventilation over more conventional modes such as AC.

Further information on the details of the different modes of ventilation and their set up can be found in the articles related to each specific mode of ventilation.

Clinical Significance

Using the Ventilator

The initial ventilator setting can vary greatly depending on the cause for intubation and the scope of this review. Nonetheless, there are some basic settings for the majority of cases.

The most common ventilator mode to use in a newly intubated patient is AC. This mode provides good comfort and easy control of some of the most important physiologic parameters.

It is started with a FiO₂ of 100% and titrated down guided by pulse oximetry or ABG, depending on the case.

Low tidal volume ventilation has been shown to be lung protective not only in ARDS but in other types of diseases. Starting the patient on a low tidal volume (6 to 8 mL/Kg of ideal body weight) will reduce the incidence of ventilator-induced lung injury (VILI). Always use a lung-protective strategy as there are not many advantages for higher tidal volumes and they will increase shear stress in the alveoli and may induce lung injury.

Initial RR should be comfortable for the patient 10-12 bpm should suffice. A very important caveat on this is for patients with severe metabolic acidosis. For these patients, the minute ventilation should at least be matched to their pre-intubation ventilation as failure to do so will worsen acidosis and can precipitate complications such as cardiac arrest.

Flow should be initiated at or above 60 L/min to prevent auto-PEEP.

Start with a low PEEP of 5 cm H₂O and titrate up as tolerated by the patient to the goal for oxygenation. Pay close attention to blood pressure and patient comfort while doing this.

An ABG should be obtained 30 minutes after intubation and changes to the ventilator settings should be made in accordance with ABG findings.

Peak and plateau pressures should be checked on the vent to assure there are no problems with airway resistance or alveolar pressure in order to prevent ventilator-induced lung injury.

Attention should be given to the volume curves in the ventilator display as a reading showing that the curve is not coming back to zero at the time of exhalation is indicative of incomplete exhalation and development of auto-PEEP and corrections to the vent should be made immediately.[7][8]

Troubleshooting the Ventilator

With a good understanding of the concepts discussed, managing ventilator complications and solving problems should come as second nature.

The most common corrections that have to be done with the vent are to solve hypoxemia and hypercapnia or hyperventilation:

- **Hypoxia:** As discussed previously, oxygenation depends on the FiO₂ and the PEEP (T high and P high for APRV). To correct for hypoxia increasing any of these parameters should raise the oxygenation. Special attention should be paid to the possible adverse effects of raising PEEP which can cause barotrauma and hypotension. Raising FiO₂ does not come without its concerns as high FiO₂ can cause oxidative damage in the alveoli. Another important aspect of managing oxygen content is to define a goal for oxygenation. In general, there is little benefit from keeping oxygen saturation above 92-94% except for cases of carbon monoxide poisoning for example. A sudden drop in oxygen saturation should raise suspicion for tube misplacement, pulmonary embolism, pneumothorax, pulmonary edema, atelectasis, or development of mucus plugs.
- **Hypercapnia:** To modify CO₂ content in blood one needs to modify alveolar ventilation. To do this, the tidal volume or the respiratory rate may be tampered with (T low and P Low in APRV). Raising the rate or the tidal volume, as well as increasing T low, will increase ventilation and decrease CO₂. Consideration has to be made while increasing the rate, as this will also increase the amount of dead space and might not be as effective as tidal volume. While increasing volume or rate special attention should be paid to the flow-volume loop to prevent the development of auto-PEEP.
- Other important circumstances are those of elevated pressures. As discussed, two pressures are important in the system: peak and plateau. The peak pressure is a measure of airway resistance as well as compliance and includes the tubing and bronchial tree. Plateau pressures are a reflection of alveolar pressure and thus of lung compliance.
- If there is an increase in peak pressure, the first step to take is to do an inspiratory hold and check the plateau.
- Elevated peak pressure and normal plateau pressure: high airway resistance and normal compliance.
- Possible causes: (1) Kinked ET tube - The solution is to unkink the tube; use a bite lock if the patient is biting on the tube, (2) Mucus plug - The solution is to suction the patient, (3) Bronchospasm - The solution is to give bronchodilators.

Elevated Peak and Elevated Plateau: Compliance Problems

Possible causes include:

- Mainstem intubation: The solution is to retract the ET tube. For diagnosis, you will find a patient with unilateral breath sounds and a dull contralateral lung (atelectatic lung).
- Pneumothorax: Diagnosis will be made by hearing breath sounds unilaterally and finding a hyper-resonant contralateral lung. In intubated patients, placement of a chest tube is imperative as the positive pressure will only worsen the pneumothorax.

- Atelectasis: Initial management consists of chest percussions and recruitment maneuvers. Bronchoscopy may be used in resistant cases
- Pulmonary edema: Diuresis, inotropes, high PEEP
- ARDS: Use low tidal volume, high PEEP ventilation

Dynamic hyperinflation or auto-PEEP: This is a process in which some of the inhaled air is not fully exhaled at the end of the respiratory cycle. The accumulation of trapped air will increase pulmonary pressures and cause barotrauma and hypotension. The patient will be difficult to ventilate. To prevent and resolve auto-PEEP, enough time should be given for the air to leave the lungs during exhalation. The goal in management is to decrease inspiratory to expiratory ratio, this can be achieved by decreasing respiratory rate, decreasing tidal volume (higher volume will require longer time to leave the lungs), and increasing inspiratory flow (if air is delivered quickly the inspiratory time is less and the expiratory time will be longer at any given respiratory rate). The same effect can be achieved by using a square waveform for inspiratory flow, what this means is that we can set the ventilator to deliver the full flow from beginning to end of inhalation. Other techniques that can be implemented are to assure adequate sedation to prevent patient hyperventilating and the use of bronchodilators and steroids to decrease airway obstruction. If auto-PEEP is severe causing hypotension, disconnecting the patient from the vent and letting time for all the air to be exhaled may be a life-saving measure. For a full description on the management of auto-PEEP please review the article titled “Positive End-Expiratory Pressure (PEEP)”

Another common problem found in mechanically ventilated patients is patient-ventilator dyssynchrony, usually termed as the patient “fighting the vent”. Important causes include hypoxia, auto-PEEP, not satisfying the patient's oxygenation or ventilation demands, pain and discomfort. After ruling out important causes as pneumothorax or atelectasis, patient comfort should be considered and proper sedation and analgesia should be assured. Consider changing the ventilator mode as some patients may respond better to different modes of ventilation.

Special Circumstances

Special attention to vent settings should be taken in the following circumstances:

COPD is a special case, as lungs in pure COPD have high compliance which causes a high tendency for dynamic airflow obstruction due to airway collapse and air trapping, making COPD patients very prone to develop auto-PEEP. Using a preventive ventilation strategy with high flow and low respiratory rate may help prevent auto-PEEP. Another important aspect to consider in chronic hypercapnic respiratory failure (due to COPD or another reason) is that there is no need to correct the CO₂ back to normal, as these patients usually have a metabolic compensation for their respiratory problems. If a patient is ventilated to normal CO₂ levels, his bicarbonate will decrease, and when a patient is extubated he will quickly go to respiratory acidosis as his kidneys cannot respond as fast as his lungs and his CO₂ will go back to his baseline, causing respiratory failure and reintubation. To prevent this, CO₂ goals should be determined based on pH and previously known or calculated baseline.

Asthma: As with COPD patients with asthma are very prone to air trapping, although the reason is pathophysiologically different. In asthma, air trapping is caused by inflammation, bronchospasm, and mucus plugs, not airway collapse. The strategy to prevent auto-PEEP is similar to the strategy used in COPD.

Cardiogenic pulmonary edema: High PEEP may decrease venous return and help resolve pulmonary edema as well as aid in cardiac output. The concern should be to make sure the patient is adequately diuresed before extubating, as the removal of the positive pressure may precipitate new pulmonary edema.

ARDS is a type of non-cardiogenic pulmonary edema. An open lung strategy with high PEEP and low tidal volume has been shown to improve mortality.

Pulmonary embolism is a difficult situation. These patients are very preload dependent secondary to the acute increase in right atrial pressure. Intubating these patients will increase RA pressure and further decrease venous return,

which may precipitate shock. If there is no way to prevent intubation, careful attention to blood pressure and initiation of vasopressors should be done promptly.

Severe pure metabolic acidosis is a concern. When intubating these patients, careful attention should be paid to their pre-intubation minute ventilation. If this ventilation is not provided when starting mechanical support, pH will drop further possibly precipitating cardiac arrest.

Other Issues

Weaning from Mechanical Ventilation

Mechanical ventilation can be a lifesaving intervention and has impacted millions of lives since its invention, but it is not without complications. Shortening the ventilator time has shown to reduce ventilation-related complications like pneumonia, so actively pursuing liberation from mechanical ventilation (the so-called ventilation weaning) is imperative in every ventilated patient.

There are simple criteria that should be satisfied before a patient is deemed ready for extubation:

- The indication for intubation and mechanical ventilation must be resolved
- The patient has to be able to maintain adequate gas exchange on its own without the help of positive pressure ventilation
- There must be no auto-PEEP
- The patient must have an adequate cardiovascular reserve (think in heart failure patients in which removing the vent can precipitate new pulmonary edema)
- There should not be copious amounts of secretions in the ET tube that could generate high airway resistance and obstruction after extubation
- The patient must be able to protect his or her airway.

After these criteria have been satisfied it is time to perform a spontaneous breathing trial (SBT). Two processes have to be completed to perform this:

1. A sedation holiday should be done daily to assess readiness for extubation with appropriate mental status and ability to protect the airway as well as to permit spontaneous breathing. This is usually protocolized in all intensive care units (ICU) and should be performed in every patient who is stable and in whom the indication for mechanical ventilation has resolved. During these daily trials, sedation is reduced to a minimum or completely eliminated until the patient is awake and cooperative but comfortable.
2. The second parameter is the SBT itself. To perform this, ventilator support should be reduced to a minimum. This can be done either via T-piece or pressure support. CPAP has been used in the past although it has been suggested to be inferior to the other two methods. A recent Cochrane review (2014) concluded that there are no major differences between T piece or pressure support trials on extubation success, reintubation, ICU mortality, or ICU length of stay. Nevertheless, pressure support was found to be superior for performing spontaneous breathing trials among patients with simple weaning (meaning patients successfully weaned in the first attempt) as it showed to have a shorter weaning time.

SBT should be performed for 30 to 120 minutes, and the patient should be monitored closely for any signs of respiratory distress. If these signs are found, the patient should be placed back on his or her prior ventilator settings. If after this time patient meets criteria for successful SBT (RR < 35bpm; no signs of distress; HR <140/min and HR variability less than 20%; O₂ sat greater than 90% or PaO₂ greater than 60 mmHg on FiO₂ less than 0.4; SBP greater than 80 and less than 180 mmHg or greater than 20% change from baseline), then the assessment for airway removal should be done by performing a cuff leak test when indicated.

If the patient is deemed ready, the ETT should be removed and the patient should be monitored closely. In patients with high risk for reintubation (failure of two or more SBTs, CHF, CO₂ greater than 45 after extubation, weak cough, pneumonia as a cause of respiratory failure), the use of noninvasive positive pressure ventilation after to extubation as a bridge to ventilator free-breathing, has been shown to reduce ICU mortality and lower risk of intubation. This effect was not seen if the patient had already developed respiratory distress. High flow nasal cannula has also shown reduced reintubation rates, although no effect on mortality has been seen.

Enhancing Healthcare Team Outcomes

There is no doubt that mechanical ventilation is a life-saving procedure that has impacted millions of lives of patients with respiratory failure around the world. It is also beneficially used in patients with chronic irreversible causes of respiratory failure like neuromuscular disease or spinal cord injuries, permitting them to live a life that would not have been possible before the creation of the mechanical ventilator. [9][10]

Mechanical ventilation requires the simultaneous skills of multiple players in the interprofessional healthcare team. The respiratory therapist is the guide on how to resolve acute issues with the ventilator. Nurses are usually the first in identifying set issues, and understanding of the physiology and management of mechanical ventilation is crucial for the clinicians managing patients in the ICU. These caregivers must alert the clinician managing the case immediately if there are any issues with ventilator use. This type of interprofessional collaboration will lead to improved results in managing patients on ventilators. [Level 5]


Questions

To access free multiple choice questions on this topic, [click here](#).

References

1. Metersky ML, Kalil AC. Management of Ventilator-Associated Pneumonia: Guidelines. *Clin. Chest Med.* 2018 Dec;39(4):797-808. [PubMed: 30390750]
2. Chomton M, Brossier D, Sauthier M, Vallières E, Dubois J, Emeriaud G, Jouvet P. Ventilator-Associated Pneumonia and Events in Pediatric Intensive Care: A Single Center Study. *Pediatr Crit Care Med.* 2018 Dec;19(12):1106-1113. [PubMed: 30234676]
3. Vandana Kalwaje E, Rello J. Management of ventilator-associated pneumonia: Need for a personalized approach. *Expert Rev Anti Infect Ther.* 2018 Aug;16(8):641-653. [PubMed: 30014727]
4. Jansson MM, Syrjälä HP, Talman K, Meriläinen MH, Ala-Kokko TI. Critical care nurses' knowledge of, adherence to, and barriers toward institution-specific ventilator bundle. *Am J Infect Control.* 2018 Sep;46(9):1051-1056. [PubMed: 29573832]
5. Piraino T, Fan E. Acute life-threatening hypoxemia during mechanical ventilation. *Curr Opin Crit Care.* 2017 Dec;23(6):541-548. [PubMed: 29016366]
6. Mora Carpio AL, Mora JI. StatPearls [Internet]. StatPearls Publishing; Treasure Island (FL): Jun 2, 2019. Ventilation Assist Control . [PubMed: 28722886]
7. Kumar ST, Yassin A, Bhowmick T, Dixit D. Recommendations From the 2016 Guidelines for the Management of Adults With Hospital-Acquired or Ventilator-Associated Pneumonia. *P T.* 2017 Dec;42(12):767-772. [PMC free article: PMC5720490] [PubMed: 29234216]
8. Del Sorbo L, Goligher EC, McAuley DF, Rubenfeld GD, Brochard LJ, Gattinoni L, Slutsky AS, Fan E. Mechanical Ventilation in Adults with Acute Respiratory Distress Syndrome. Summary of the Experimental Evidence for the Clinical Practice Guideline. *Ann Am Thorac Soc.* 2017 Oct;14(Supplement_4):S261-S270. [PubMed: 28985479]
9. Chao CM, Lai CC, Chan KS, Cheng KC, Ho CH, Chen CM, Chou W. Multidisciplinary interventions and continuous quality improvement to reduce unplanned extubation in adult intensive care units: A 15-year experience. *Medicine (Baltimore).* 2017 Jul;96(27):e6877. [PMC free article: PMC5502132] [PubMed: 28682859]
10. Badnjevic A, Gurbeta L, Jimenez ER, Iadanza E. Testing of mechanical ventilators and infant incubators in healthcare institutions. *Technol Health Care.* 2017;25(2):237-250. [PubMed: 28387686]

Figures



Assist control (AC) ventilation. Contributed by Andres Mora, MD

Copyright © 2020, StatPearls Publishing LLC.

This book is distributed under the terms of the Creative Commons Attribution 4.0 International License (<http://creativecommons.org/licenses/by/4.0/>), which permits use, duplication, adaptation, distribution, and reproduction in any medium or format, as long as you give appropriate credit to the original author(s) and the source, a link is provided to the Creative Commons license, and any changes made are indicated.

Bookshelf ID: NBK448186 PMID: 28846232